

FIXTURE REPLACEMENT INSTRUCTIONS

For LEDC11 & RGBC5 WaterGlow Lighting

NOTE This replacement light fixture includes a Quick Disconnect coupling and a heat-shrink tube.

PARTS OVERVIEW



INSTRUCTIONS

1. Remove the old fixture by removing the heat shrink tube (if applicable), unthreading the Connector Nut, and separating the Cord Splitter from the Fixture boot.
2. Ensure that the female (Cord Splitter side) half of the connection is clean and dry. If it is not, remove any debris and allow to dry thoroughly before assembling.
3. Inspect the Cord Splitter side of the connection for damage.
 - If no damage is present, proceed to step 4.
 - If damage is present, replace the splitter or call Kasco for technical support (715-262-4488).
4. Confirm the o-ring is present on the male (Fixture) side of the connection. The connection will not be water-tight without it.
5. Slide the 1" piece of shrink tube over the female connector of the Cord Splitter and slide it down the cord towards the splitter, exposing the connector for assembly.

INSTRUCTIONS (CONT.)

6. Connect the Fixture connector to the Cord Splitter connector.



7. Slide the Nut from the Fixture half of the connector over until it engages the threads on the Cord Splitter half of the connector. Turn clockwise to secure the two halves snugly together. (Note: over-tightening may damage components.)



8. Slide the shrink tube over the cord connection and center it on the connection.



9. Use a heat gun to shrink the tubing down to secure the connection and create an additional seal against water intrusion. (Do not apply excessive heat directly to shrink tube or assembly, as overheating may result in damage to components.)

